

**DISKY pro Krouhač zeleniny GMS601 Bartscher a ostatní doplňky**



12264 75



12264 92



12264 76



12264 93



12264 94



12264 77



12264 95



12264 78




12265 05



12265 07

**Stojan na disky**





12264 81



12264 82



12264 80



12264 83



12264 88



12264 89



12264 79



12264 91

nádoba ke krouhači GMS601 – nerez

nádoba ke krouhači GMS601 - plast

